

Hanging Baskets

Irrigation options for Hanging Baskets with XBCV Emitters and Dripline



ADVANTAGES:

- Up to 60% water savings
- Targeted watering in baskets
- Eliminates hand watering
- Connect to irrigation controller for consistent automatic watering
- XBCV Emitters feature built-in check valves which eliminates low point drainage and runoff by holding back water up to 10 ft. when system is off

INSTALLATION SOLUTIONS:

Option A

Poly Tubing Lateral with Xeri-Bug Emitters

XCZ-075-PRF	3/4" Control Zone with 40 psi Pressure Regulator
XBS	Xeri Black Stripe Poly Tubing
XBCV-XXPC	Xeri-Bug Emitters with Check Valve (0.5 to 2.0 gph)
XQ-100	1/4" Distribution Tubing
XM Tool	XM Installation Tool
Electrical Staples	1/2" Metal Staples
TS-025	1/4" Tubing Stake

* Select appropriate emitter flow rate and barbed connection

TO-DO LIST:

- | | |
|--|------------------------|
| <input type="checkbox"/> Assemble Control Zone Kit at water source and connect poly tube laterals to edge of structure. | TIME A:
1 hr |
| <input type="checkbox"/> Elbow poly lateral in vertical line up structure to eaves Staple poly lateral to structure. | 40 min/50' |
| <input type="checkbox"/> Staple poly lateral along underside of eaves. | 5 min |
| <input type="checkbox"/> Use XM tool to punch 1/4" barb connector into poly Lateral above baskets. | 1 min/Basket |
| <input type="checkbox"/> Insert 1/4" barb connector into the poly line, Connect short length of 1/4" tubing to the barb connector. | 1 min/Basket |
| <input type="checkbox"/> Insert Xeri-Bug w/ Check Valve emitter at the other end of the 1/4" tubing Stake tubing in basket. | 1 min/Basket |

Option B

Poly Tubing Lateral with 1/4" Landscape Dripline Loop

XCZ-075-PRF	3/4" Xeri Control Zone Kit
XBS	Xeri Black Stripe Poly Tubing
XQ-100	1/4" Distribution Tubing
XBF1CONN	1/4" Barb Connector
XBF 3TEE	1/4" Barb Tee
LDQ-08-06-100	1/4" Landscape Dripline

TO-DO LIST:

- | | |
|--|------------------------|
| <input type="checkbox"/> Assemble Control Zone Kit at water source and connect poly tube laterals to edge of structure. | TIME B:
1 hr |
| <input type="checkbox"/> Use XM Tool to punch 1/4" barb connector into poly lateral alongside potted plant. | 1 min |
| <input type="checkbox"/> Connect a length of 1/4" Distribution tubing into a drilled hole at the bottom of the pot. | 5 min |
| <input type="checkbox"/> Using 1/4" dripline, form a circular ring and connect to distribution tubing using a 1/4" barb tee. | 5 min |

INSTALLATION AND MAINTENANCE TIPS:

- Flush the zone after installation and 2-4 times per year.
- Use XM Tool for faster installation of Xeri-Bug Emitters and 1/4" barb connectors.
- Break up watering cycles to avoid excess drainage.

