


- ① LOW VOLUME SPRAY NOZZLE:
RAIN BIRD SQ SERIES NOZZLE
(FORMERLY KNOWN AS XPCN)
(1 OF 2 SHOWN)
- ② POLYFLEX RISER ADAPTER:
RAIN BIRD SQ ADP
(1 OF 2 SHOWN)
- ③ POLYFLEX RISER AND STAKE ASSEMBLY:
RAIN BIRD PFR-RS (1 OF 2 SHOWN)
- ④ ¼" DISTRIBUTION TUBING:
RAIN BIRD XQ TUBING
(1 OF 2 SHOWN)
(LENGTH AS REQUIRED)
- ⑤ ¼" BARB TRANSFER TEE:
RAIN BIRD XBF3TEE
- ⑥ ½" POLYETHYLENE TUBING:
RAIN BIRD XF SERIES TUBING OR
RAIN BIRD XT-700 XERI-TUBE OR
RAIN BIRD XBS BLACK STRIPE TUBING
- ⑦ TOP OF MULCH
- ⑧ FINISH GRADE

NOTES:

1. USE RAIN BIRD XERIMAN TOOL XM-TOOL TO INSERT TRANSFER TEE DIRECTLY INTO ½" POLYETHYLENE TUBING.
2. RAIN BIRD SQ SQUARE NOZZLE SERIES ARE AVAILABLE IN THE FOLLOWING MODELS:
SQ QTR - QUARTER PATTERN - 7.4 GPH MAX
SQ HLF - HALF PATTERN - 13.7 GPH MAX
SQ FUL - FULL PATTERN - 27.3 GPH MAX
3. SQ NOZZLES CAN BE ADJUSTED FROM 2.5' THROW TO 4' THROW BY TURNING THE NOZZLE.

**SQ NOZZLE WITH ADAPTER ON POLYFLEX RISER
STAKE FROM BARBED TRANSFER TEE**

1-13-10



N.T.S.

**INTO 1/2" POLYETHYLENE TUBING
OPTION 5**