



NOTES:

1. PLACE TIE DOWN STAKES EVERY THREE FEET IN SAND, FOUR FEET IN LOAM, AND FIVE FEET IN CLAY.
2. AT FITTINGS WHERE THERE IS A CHANGE OF DIRECTION SUCH AS TEES OR ELBOWS, USE TIE-DOWN STAKES ON EACH LEG OF THE CHANGE OF DIRECTION.
3. SAVE YOUR HANDS. USE THE RAIN BIRD FITTINGS-TOOL XF INSERTION TOOL FOR FITTING ASSEMBLY.

- ① ON-SURFACE DRIPLINE:  
RAIN BIRD XF SERIES DRIPLINE  
POTABLE: XFS DRIPLINE  
NON-POTABLE: XFSP DRIPLINE
- ② INLINE DRIP EMITTER OUTLET, SEE PLANS FOR DRIPLINE OUTLET SPACING.
- ③ BARB TEE 17x17x17mm  
RAIN BIRD XFF-TEE
- ④ BARB COUPLING 17x17mm  
RAIN BIRD XFF-COUP
- ⑤ BARB ELBOW 17x17mm  
RAIN BIRD XFF-ELBOW
- ⑥ BARB MALE ADAPTER  
17mm X 1/2" MPT  
RAIN BIRD XFF-MA-050  
17mm X 3/4" MPT  
RAIN BIRD XFF-MA-075
- ⑦ PVC TEE SxSxT
- ⑧ PVC LATERAL SUPPLY HEADER
- ⑨ TIE DOWN STAKE:  
RAIN BIRD TDS-050 WITH BEND (TYPICAL)
- ⑩ FINISH GRADE
- ⑪ RAIN BIRD XF SERIES BLANK TUBING  
LENGTH AS REQUIRED



## XFS SUB-SURFACE DRIPLINE RISER ASSEMBLY

N.T.S.

12-18-2012