


- ① MICRO-SPRAY WITH 1032 THREADED INLET:
RAIN BIRD XERI-SPRAY
(1 OF 2 SHOWN)
- ② POLYFLEX RISER AND STAKE ASSEMBLY:
RAIN BIRD PFR-RS (1 OF 2 SHOWN)
- ③ 1/4" DISTRIBUTION TUBING:
RAIN BIRD XQ TUBING
(LENGTH AS REQUIRED)
(1 OF 2 SHOWN)
- ④ 1/4" BARB TRANSFER TEE:
RAIN BIRD XBF3TEE
- ⑤ 1/2" POLYETHYLENE TUBING:
RAIN BIRD XF SERIES TUBING OR
RAIN BIRD XT-700 XERI-TUBE OR
RAIN BIRD XBS BLACK STRIPE TUBING
- ⑥ TOP OF MULCH
- ⑦ FINISH GRADE

NOTES:

- 1. USE RAIN BIRD XERIMAN TOOL XM-TOOL TO INSERT TRANSFER TEE
DIRECTLY INTO 1/2" POLYETHYLENE TUBING.
- 2. RAIN BIRD XERI-SPRAY AVAILABLE IN THE FOLLOWING MODELS:
XS-090 - QUARTER CIRCLE - SPRAY - 31 GPH MAX
XS-180 - HALF CIRCLE - SPRAY - 31 GPH MAX
XS-360 - FULL CIRCLE - STREAM SPRAY - 31 GPH MAX
X360 ADJMST - FULL CIRCLE - MIST - 31 GPH MAX

XERI-SPRAY 1032 THREADED ON A POLYFLEX
RISER STAKE INTO 1/2" POLYETHYLENE



N.T.S.

TUBING WITH 1/4" TRANSFER BARB
AND TUBING - OPTION 2

1-21-10