



- ① MICRO-SPRAY WITH THREADED INET:  
RAIN BIRD XERI-SPRAY 360° TRUE SPRAY  
1032 THREADED
- ② TOP OF MULCH
- ③ FINISH GRADE
- ④ POLYFLEX RISER AND ADAPTER ASSEMBLY:  
RAIN BIRD PFR-FRA
- ⑤ PVC SCH 40 TEE OR ELL
- ⑥ PVC LATERAL PIPE

XERI-SPRAY 360 TRUE SPRAY 1032 ON  
POLYFLEX RISER INTO PVC TEE

D

N.T.S.

OPTION 1A

1-21-10