



- ① MICRO-SPRAY WITH THREADED INET:  
RAIN BIRD XERI-SPRAY 360° TRUE  
SPRAY 1032 THREADED  
(1 OF 2 SHOWN)
- ② POLYFLEX RISER AND STAKE ASSEMBLY:  
RAIN BIRD PFR-RS (1 OF 2 SHOWN)
- ③ ¼" DISTRIBUTION TUBING:  
RAIN BIRD XQ TUBING  
(LENGTH AS REQUIRED)  
(1 OF 2 SHOWN)
- ④ ¼" BARB TRANSFER TEE:  
RAIN BIRD XBF3TEE
- ⑤ ½" POLYETHYLENE TUBING:  
RAIN BIRD XF SERIES TUBING OR  
RAIN BIRD XT-700 XERI-TUBE OR  
RAIN BIRD XBS BLACK STRIPE TUBING
- ⑥ TOP OF MULCH
- ⑦ FINISH GRADE

NOTE:

- 1. USE RAIN BIRD XERIMAN TOOL XM-TOOL TO INSERT TRANSFER TEE  
DIRECTLY INTO ½" POLYETHYLENE TUBING.

**XERI-SPRAY 360 TRUE SPRAY 1032 THREADED  
ON POLYFLEX RISER STAKE INTO**

**D**

N.T.S.

**1/2" POLYETHYLENE TUBING WITH 1/4" TRANSFER  
CONNECTOR AND TUBING - OPTION 2**

1-21-10