



- ① MICRO-SPRAY WITH THREADED INET:
RAIN BIRD XERI-SPRAY 360° TRUE
SPRAY 1032 THREADED
- ② 12" POLYFLEX RISER:
RAIN BIRD PFR-12
- ③ THREADED RISER STAKE:
RAIN BIRD RS-025T
- ④ 1/4" DISTRIBUTION TUBING:
RAIN BIRD XQ TUBING
(LENGTH AS REQUIRED)
- ⑤ TOP OF MULCH
- ⑥ 1/4" BARB TRANSFER CONNECTOR:
RAIN BIRD XBF1CONN
- ⑦ 1/2" POLYETHYLENE TUBING:
RAIN BIRD XF SERIES TUBING OR
RAIN BIRD XT-700 XERI-TUBE OR
RAIN BIRD XBS BLACK STRIPE TUBING
- ⑧ FINISH GRADE

NOTE:

- 1. USE RAIN BIRD XERIMAN TOOL XM-TOOL TO INSERT TRANSFER TEE
DIRECTLY INTO 1/2" POLYETHYLENE TUBING.

**XERI-SPRAY 360 TRUE SPRAY 1032 THREADED
WITH POLYFLEX RISER AND STAKE INTO**

1-21-10

D

**N.T.S. 1/2" POLYETHYLENE TUBING WITH 1/4" TRANSFER
CONNECTOR AND TUBING - OPTION 3**