


- ① MICRO-SPRAY WITH BARB INET:
RAIN BIRD XERI-SPRAY 360° TRUE SPRAY
- ② UNIVERSAL 1/4" TUBING STAKE:
RAIN BIRD TS-025
- ③ 1/4" DISTRIBUTION TUBING:
RAIN BIRD XQ TUBING
(LENGTH AS REQUIRED)
- ④ TOP OF MULCH
- ⑤ 1/4" BARB CONNECTOR INCLUDED ON
XERI-BUBBLER SPIKE
- ⑥ 1/2" POLYETHYLENE TUBING:
RAIN BIRD XF SERIES TUBING OR
RAIN BIRD XT-700 XERI-TUBE OR
RAIN BIRD XBS BLACK STRIPE TUBING
- ⑦ FINISH GRADE

NOTES:

- 1. SHOULD MICRO-SPRAY BECOME DISLODGED UNREGULATED FLOW WILL OCCUR.
- 2. USE RAIN BIRD XERIMAN TOOL XM-TOOL TO INSERT BARB CONNECTOR
DIRECTLY INTO 1/2" POLYETHYLENE TUBING.

XERI-SPRAY 360 TRUE SPRAY INTO
1/2" POLYETHYLENE TUBING WITH



N.T.S.

1/4" TRANSFER BARB AND TUBING
OPTION 1

1-21-10