



- ① MICRO-SPRAY WITH BARB INET:  
RAIN BIRD XERI-SPRAY 360° TRUE SPRAY  
(1 OF 2 SHOWN, 6 POSSIBLE)
- ② UNIVERSAL 1/4" TUBING STAKE:  
RAIN BIRD TS-025  
(1 OF 2 SHOWN, 6 POSSIBLE)
- ③ 1/4" DISTRIBUTION TUBING:  
RAIN BIRD XQ TUBING (LENGTH AS REQUIRED)  
(1 OF 2 SHOWN, 6 POSSIBLE)
- ④ SUBTERRANEAN EMITTER BOX:  
RAIN BIRD SEB 7XB
- ⑤ SIX OUTLET MANIFOLD:  
RAIN BIRD EMT-6XERI
- ⑥ TOP OF MULCH
- ⑦ FINISH GRADE
- ⑧ PVC SCH 80 NIPPLE  
(LENGTH AS REQUIRED)
- ⑨ PVC SCH 40 TEE OR ELL
- ⑩ PVC LATERAL PIPE
- ⑪ 3" MINIMUM DEPTH OF  
3/4" WASHED GRAVEL

NOTE:

1. SHOULD MICRO-SPRAY BECOME DISLODGED UNREGULATED FLOW WILL OCCUR.

XERI-SPRAY 360 TRUE SPRAY FROM  
6 OUTLET MANIFOLD INTO PVC

N.T.S.

WITH 1/4" TUBING - OPTION 2A

1-21-10

