


- ① MICRO-SPRAY ON 1/4" TUBING STAKE:  
RAIN BIRD XERI-SPRAY 360° TRUE  
SPRAY SPIKE
- ② 1/4" DISTRIBUTION TUBING:  
RAIN BIRD XQ TUBING  
(LENGTH AS REQUIRED)
- ③ 1/4" BARB CONNECTOR INCLUDED ON  
XERI-BUBBLER SPIKE
- ④ 1/2" POLYETHYLENE TUBING:  
RAIN BIRD XF SERIES TUBING OR  
RAIN BIRD XT-700 XERI-TUBE OR  
RAIN BIRD XBS BLACK STRIPE TUBING
- ⑤ TOP OF MULCH
- ⑥ FINISH GRADE

NOTE:

- 1. USE RAIN BIRD XERIMAN TOOL XM-TOOL TO INSERT BARB CONNECTOR  
DIRECTLY INTO 1/2" POLYETHYLENE TUBING.

XERI-SPRAY 360 TRUE SPRAY SPIKE INTO  
1/2" POLYETHYLENE TUBING WITH



N.T.S.

1/4" TRANSFER BARB AND TUBING  
OPTION 1

1-21-10