



Ref.	Part Description	20AH	20AH PM	20AH
		20A TNT	ALUM	20A TNT
		ALUM	ALUM	(C) BRONZE
<b>UPPER ASSEMBLY</b>				
1	Fulcrum Pin	100793	100793	100793
2	Arm Hood	100775	100775	100775
3	Arm Spring Assembly	115306	115306	(102254)
4	Arm Spring	100172	100172	100133
5	Arm Bumper (Since 93/94)	101156	101156	101156
5	Arm Bumper (Old Style round arm)	101156	101156	101156
6	Arm Bushing	111731	111731	-
7	Arm Washer	100173	100173	100173
8	Arm Wear Washer	103080	103080	-
<b>NOZZLES (Specify nozzle size when ordering)</b>				
9	Straight Bore	105780	105780	105780
-	Low Angle 5 Degree	104590	104590	-
-	Low Angle 7 Degree	100225	100225	100225
-	Low Angle 12 Degree	100622	100622	100622
-	Low Angle 20 Degree	100226	100226	100226
-	Low Angle 23 Degree	100227	100227	100227
-	Low Pressure 0 Degree	104571	-	-
-	Plastic Quick Fit SBN (B)	117324	117324	-
<b>BEARING ASSEMBLY</b>				
10	Bearing Assembly (H Style)	118343	104792	(108963)
11	Top Seal Washer (Black)	104183	104183	104183
12	Metal Top Seal Washer	100280	100280	100280
13	Bearing Spring	105431	105431	100272
14	Bearing Sleeve (Brass)	104153	-	104153
14	Bearing Sleeve (Plastic)	-	(104631)	-
15	Bearing Washer (2) (Black)	104181	104181	104181
16	Wear Washer (O-Orange, W-White) (W)	104696	(W)104696	(O)104184
17	Bearing Nipple	102020	102020	102020
<b>Bearing Assembly (Old TNT Style) (A)</b>				
19	Bearing Spring	100182	-	100182
20	Skirted Top Seal Washer (Black)	100180	-	100180
21	Top Seal Washer (White)	100181	-	100181
22	Bearing Sleeve (A)	(A)	-	(A)
23	Wearing Ring (T-Ring)(Orange)	(102704)	-	(102704)
24	Bearing Washer (Black)	104181	-	104181
25	Bearing Nipple	100178	-	100178
<b>Bearing Assembly (TNT Replacment)</b>				
18	Bearing Assembly (TNT Replacment)	110949	-	110949
19	Bearing Spring	100182	-	100182
20	Skirted Top Seal Washer (Black)	100180	-	100180
21	Top Seal Washer (White)	100181	-	100181
22	Bearing Sleeve (A)	(A)	-	(A)
23	Bearing Washer (2) (Black)	104181	-	104181
24	Wear Washer (Orange)	104184	-	104184
25	Bearing Nipple	100178	-	100178

(A) Bearing sleeve not available. Use 110949 Bearing Assembly.  
 (B) To be used with 117312 Quick Fit Connector.  
 (C) Not available; no replacement

Note: Part numbers enclosed in brackets ( ) are not available individually, but may be sold in assemblies or kits.