



| Ref. | Description | Qty. | E-4c | E-6c | E-9c |
|--------------------|--------------------------------|------|-------------|-------------|-------------|
| 1 | Front Panel Assembly | 1 | (634154-01) | (634154-02) | (634154-03) |
| 2 | Rotary Knob, EC | 1 | 634063 | 634063 | 634063 |
| 3 | Lower Access Door Assembly | 1 | 634155 | 634155 | 634155 |
| ACCESSORIES | | | | | |
| 4 | Wiring Skirt | 1 | 633943 | 633943 | 633943 |
| 5 | Battery 9V | 1 | (651405) | (651405) | (651405) |
| 6 | Transformer Assy 120VAC, 60Hz | 1 | 637473-01S | 637473-01S | 637473-01S |
| - | E-c Programming Card | 1 | (634159) | (634159) | (634159) |
| - | E-c Quick Reference Card | 1 | 634150 | 634150 | 634150 |
| - | Manual, English/Spanish/French | 1 | 634957 | 634957 | 634957 |
| - | Mounting Template E-c | 1 | (634158) | (634158) | (634158) |

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.