



Ref.	Part Description	F2004 (1997-1998)
1	Forward Arm Assembly	71-P50332
2	Forward Spoon Bracket Assembly	71-P00364
3	Ball Bearing	71-P00324
4	Arm Nut (2)	Included in Kit B
5	Arm Cap	Included in Kit B
6	Forward Arm Spring	71-P50295
8	Elbow/Range Tube Assembly	71-P50308
9	Locknut Seal (2)	Included in Kit A
10	Brake Assembly**	71-P50814 + 71-P51002
11	Bearing Assembly**	71-P50814 + 71-P51002
14	Snap Ring	71-P50344
15	Ball Bearing	71-P50549
16	Lock Nut	Included in Ref. 11
17	Lower Bearing Seal	71-102155
18	Bearing Sleeve	Included in Ref. 11
19	Arm Shaft	Included in Kit B
20	Nozzle Retainer	71-P50302
21	GNS-2005T Taper Bore Nozzle (6) Set*	L00250
22	GNS-2005O Ring Nozzle (6) Set*	L00255
23	Bearing Wrench (1999)	71-P50697

SPARE PART KITS		
A	Maintenance Kit	71-P50364
B	Arm Shaft Kit	71-P50425

\* Consult current Agricultural Equipment Price List  
 \*\* Both parts must be ordered to replace the original part.

Note: Part numbers enclosed in brackets ( ) are not available individually, but may be sold in assemblies or kits.




Ref.	Part Description	F2004 (1999)
1	Arm Nut	Included in Kit B
2	Arm Shaft	Included in Kit B
3	Nozzle Retainer	71-P50302
4	Forward Spoon Bracket Assembly	71-P00364
5	Forward Arm Assembly	71-P50807
6	Arm Ball Bearing	71-P00324
7	Arm Nut	Included in Kit B
8	Arm Cap	Included in Kit B
9	Forward Arm Spring	71-P50295
10	Elbow/Range Tube Assembly	71-P50803
11	O-Ring	Included in Kit A
12	Brake Assembly	71-P50814
13	Bearing Assembly	71-P51002
14	GNS-2005T Taper Bore Nozzle (6) Set*	L00250
15	GNS-2005O Ring Nozzle (6) Set*	L00255
16	Bearing Wrench (1999)	71-P50697

Spare Part Kits		
A	Maintenance Kit	71-P50364
B	Arm Shaft Kit	71-P50425

\* Consult current Agricultural Equipment Price List

Note: Part numbers enclosed in brackets ( ) are not available individually, but may be sold in assemblies or kits.



Ref.	Part Description	F2004 (2000)
01	Arm Nut (2)	Included in Kit B
02	Arm Shaft	Included in Kit B
03	Nozzle Retainer	71-P50302
04	Forward Spoon Bracket Assembly	71-P00364
05	Forward Arm Assembly	71-P50807
06	Arm Ball Bearing	71-P00324
07	Arm Cap	Included in Kit B
08	Forward Arm Spring	71-P50295
09	Elbow/Range Tube Assembly	71-P50803
10	O-Ring (2 required)	Included in Kit A
11	Brake Assembly	71-P50814
12	Bearing Assembly	71-P51002
13	Snap Ring	71-P50344
14	Ball bearing	71-P50549
15	Lock Nut	71-P50796
16	O-Ring	71-102155
17	Bearing Sleeve	71-P50795
18	GNS-2005T Taper Nozzle (6) Set*	L00250
19	GNS-2005O Ring Nozzle (6) Set*	L00255
23	Pressure Port Plug	71-P20006

**ACCESSORIES**

20	Bearing Wrench	71-P50697
21	Riser installation Kit	71-P00368
22	Rear Counterweight*	L00260

**SPARE PART KITS**

A	Maintenance Kit	71-P50364
B	Arm Shaft Kit	71-P50425

\* Consult current Agricultural Equipment Price List.

Note: Part numbers enclosed in brackets ( ) are not available individually, but may be sold in assemblies or kits.