

Ref.	Part Description	SR2005 (1997-1998)
01	Reverse Arm Assembly	71-P50333
02	Reverse Spoon Bracket Assembly	71-P00382
03	Nozzle Retainer	71-P50302
04	Forward Arm Assembly	71-P50332
05	Forward Spoon Bracket Assembly	71-P00364
06	Ball Bearing	71-P00324
07	Arm Nut (2)	Included in Kit B
08	Arm Cap (2)	Included in Kit B
09	Trip Yoke Assembly	71-P50215
10	Upper Bushing	Included in Kit A
12	Elbow/Range Tube Assy	71-P50308
13	Lower Bushing	Included in Kit A
14	Brake Assembly**	71-P50814 + 71-P50975
15	Bearing Assembly**	71-P50814 + 71-P50975
16	Bearing Sleeve	Included in Ref. 15
17	Friction Collar	71-P50116
18	Lower Bearing Seal	71-102155
19	Lock Nut	Included in Ref 15
20	Lock Nut Seal (2)	Included in Kit A
21	Ball Bearing	71-P50549
22	Snap Ring	71-P50344
24	Trip Spring	Included in Ref. 26
25	Trip lever Bushing	Included in Kit A
26	Trip Lever Assembly	71-P50331
27	Arm Shaft	Included in Kit B
28	Forward Arm Spring	71-P50295
29	Reverse Arm Spring	71-P50296
30	GNS-2005T Taper Bore Nozzle (6) Set*	L00250
31	GNS-2005O Ring Nozzle (6) Set*	L00255
32	Bearing Wrench (1999)	71-P50697


SPARE PART KITS

A	Maintenance Kit	71-P50364
B	Arm Shaft Kit	71-P50365

* Consult current Agricultural Equipment Price List

** Both Parts Must Be Ordered to Replace the Original part.

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.




Ref.	Part Description	SR2005 (1999)
1	Arm Cap (2)	Included in Kit B
2	Arm Nut (2)	Included in Kit B
3	Arm Shaft	Included in Kit B
4	Reverse Spoon Bracket Assembly	71-P00382
5	Reverse Arm Assembly	71-P50809
6	Nozzle Retainer	71-P50302
7	Forward Spoon Bracket Assembly	71-P00364
8	Forward Arm Assembly	71-P50807
9	Arm Ball Bearing	71-P00324
10	Forward Arm Spring	71-P50295
11	Trip Yoke Assembly	71-P50215
12	Upper Yoke Bushing	Included in Kit A
13	Elbow/Range Tube Assembly	71-P50803
14	O-Ring	Included in Kit A
15	Brake Assembly	71-P50814
16	Bearing Assembly	71-P50975
17	Friction Collar (2 Required)	71-P50116
19	Lower Yoke Bushing	Included in Kit A
20	Trip Lever Bushing	Included in Kit A
21	Trip Lever Assembly	71-P50331
22	Reverse Arm Spring	71-P50296
23	GNS-2005T Taper Bore Nozzle (6) Set*	L00250
24	GNS-2005O Ring Nozzle (6) Set*	L00255
25	Bearing Wrench (1999)	71-P50697

SPARE PART KITS

A	Maintenance Kit	71-P50364
B	Arm Shaft Kit	71-P50365

* Consult current Agricultural Equipment Price List

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.



Ref. Part Description SR2005 (2000)

01	Arm Cap (2)	Included in Kit B
02	Arm Nut (2)	Included in Kit B
03	Arm Shaft	Included in Kit B
04	Reverse Spoon Bracket Assembly	71-P00382
05	Reverse Arm Assembly	71-P50809
06	Nozzle Retainer	71-P50302
07	Forward Spoon Bracket Assembly	71-P00364
08	Forward Arm Assembly	71-P50807
09	Arm Ball Bearing	71-P00324
10	Forward Arm Spring	71-P50295
11	Trip Yok Assembly	71-P50215
12	Upper Yoke Bushing	Included in Kit A
13	Elbow/Range Tube Assembly	71-P50803
14	O-Ring (2 required)	Included in Kit A
15	Brake Assembly	71-P50814
16	Bearing Assembly	71-P50975
17	Friction Collar (2 required)	71-P50116
18	Snap Ring	71-P50344
19	Ball bearing	71-P50549
20	Lock Nut	71-P50796
21	O-Ring	71-102155
22	Bearing Sleeve	71-P50795
23	Lower Yoke Bushing	Included in Kit A
24	Trip Lever Bushing	Included in Kit A
25	Trip Lever Assembly	71-P50331
26	Reverse Arm Spring	71-P50296
27	GNS-2005T Taper Nozzle (6) Set*	L00250
28	GNS-2005O Ring Nozzle (6) Set*	L00255
32	Pressure Port Plug	71-P20006

ACCESSORIES

29	Bearing Wrench	71-P50697
30	Riser installation Kit	71-P00368
31	Rear Counterweight*	L00260

SPARE PART KITS

A	Maintenance Kit	71-P50364
B	Arm Shaft Kit	71-P50365

* Consult current Agricultural Equipment Price List.

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.