



- ① ET MANAGER RECEIVER (ETMR)
- ② RUBBER GASKET (INCLUDED)
- ③ 1/2" CONDUIT NUT (INCLUDED)
- ④ JUNCTION BOX WITH COVER AND 3/4" SCREWS (INCLUDED)
- ⑤ CABLE AND CONNECTOR FOR ET MANAGER RECEIVER
- ⑥ 30' EXTENSION CABLE WITH RJ45 MALE AND FEMALE CONNECTIONS (INCLUDED)
- ⑦ 1 3/4" #6 SHEET METAL SCREW WITH ANCHOR (1 OF 4)
- ⑧ 3/4" CONDUIT (NOT INCLUDED)
- ⑨ MOUNT ETMR USING REMOTE MOUNTING KIT (ETM-RMK) ON FLAT SURFACE NO FURTHER THAN 30' AWAY FROM CONTROLLER. INSTALL SO RECEIVER IS SET VERTICALLY AS SHOWN.

D

**ET Manager Receiver**  
 N.T.S.  
**Remote Mounting Kit**

2-04-09