



Ref.	Part Description	SR2005 (1997-1998)
01	Reverse Arm Assembly	71-P50333
02	Reverse Spoon Bracket Assembly	71-P00382
03	Nozzle Retainer	71-P50302
04	Forward Arm Assembly	71-P50332
05	Forward Spoon Bracket Assembly	71-P00364
06	Ball Bearing	71-P00324
07	Arm Nut (2)	Included in Kit B
08	Arm Cap (2)	Included in Kit B
09	Trip Yoke Assembly	71-P50215
10	Upper Bushing	Included in Kit A
12	Elbow/Range Tube Assy	71-P50308
13	Lower Bushing	Included in Kit A
14	Brake Assembly**	71-P50814 + 71-P50975
15	Bearing Assembly**	71-P50814 + 71-P50975
16	Bearing Sleeve	Included in Ref. 15
17	Friction Collar	71-P50116
18	Lower Bearing Seal	71-102155
19	Lock Nut	Included in Ref 15
20	Lock Nut Seal (2)	Included in Kit A
21	Ball Bearing	71-P50549
22	Snap Ring	71-P50344
24	Trip Spring	Included in Ref. 26
25	Trip lever Bushing	Included in Kit A
26	Trip Lever Assembly	71-P50331
27	Arm Shaft	Included in Kit B
28	Forward Arm Spring	71-P50295
29	Reverse Arm Spring	71-P50296
30	GNS-2005T Taper Bore Nozzle (6) Set*	L00250
31	GNS-2005O Ring Nozzle (6) Set*	L00255
32	Bearing Wrench (1999)	71-P50697

**SPARE PART KITS**

A	Maintenance Kit	71-P50364
B	Arm Shaft Kit	71-P50365

\* Consult current Agricultural Equipment Price List

\*\* Both Parts Must Be Ordered to Replace the Original part.

Note: Part numbers enclosed in brackets ( ) are not available individually, but may be sold in assemblies or kits.