



Ref.	Part Description	JTV/AS-07	JTV/AS-100	JTV/ASF-075	JTV/ASF-100	100-JTV/AVB	075-JTV/AVB
A	SOLENOID ASSY	B60599	B60599	B60599	B60599	B60599	B60599
1	Bonnet	(231761-01)	(231761-01)	(232949-01)	(232949-01)	(232949-01)	(232949-01)
2	Flow Control Handle	-	-	(240065)	(240065)	(240065)	(240065)
3	Screw, Bleed	(234999)	(234999)	(234999)	(234999)	(234999)	(234999)
4	Flow Control Stem	-	-	(233517)	(233517)	(233517)	(233517)
5	Flow Control Piston	-	-	(232950)	(232950)	(232950)	(232950)
6	Cap & Cover Assy	(233800)	(233800)	(233800)	(233800)	(233680)	(233680)
7	Cap Washer	(234868)	(234868)	(234868)	(234868)	(234868)	(234868)
8	Vacuum Breaker Piston	(231917)	(231917)	(231917)	(231917)	(231917)	(231917)
9	Piston Washer	(234932)	(234932)	(234932)	(234932)	(234932)	(234932)
B	DIAPHRAGM ASSY	B36330	B36330	B36330	B36330	B36330	B36330
10	Diaphragm Spring	(206944)	(206944)	(206944)	(206944)	(206944)	(206944)
11	Diaphragm	(232770)	(232770)	(232770)	(232770)	(232770)	(232770)
12	Body	-	-	-	-	-	-

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.