



Ref.	Part Description	30IBH 30IEBH
UPPER ASSEMBLY		
1	Fulcrum Pin	100271
2	Arm Hood	100968
3	Arm Spring Assembly	104236
4	Arm Spring	100305
5	Arm Washer	100270
NOZZLES (Specify nozzle size when ordering)		
6	Straight Bore w/Vane	106131
7	Spreader 7 Degree	100225
7	Spreader 20 Degree	100226
7	Spreader Plug (W Model)	100255
BEARING ASSEMBLY		
10	Bearing Assembly (Standard H Style)	104152
11	Top Seal Washer	103709
12	Metal Top Seal Washer	100312
13	Bearing Spring	106237
14	Bearing Sleeve	103670
15	Bearing Washer (Black)	100726
16	Wear Washer (T-Ring) (Orange)	103058
17	Seal Washer (Gray)	102345
18	Bearing Nipple	103669

Consult current Agricultural Equipment Price List.

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.