




CLP	HP	VFD	Pump	Housing	Piping	Volt	Phase	Part Number	Description
CLP	05	V	A	A	S	C	1	CLP05VAASC1	CLP5A,VFD,BST,AL,SS,200V,1P 3P
CLP	05	V	C	A	S	C	1	CLP05VCASC1	CLP5C,VFD,BST,AL,SS,200V,1P 3P
CLP	05	V	B	A	S	C	1	CLP05VBASC1	CLP5B,VFD,BST,AL,SS,200V,1P 3P
CLP	07	V	D	A	S	E	1	CLP07VDASE1	CLP7D,VFD,BST,AL,SS,200V,1P 3P
CLP	07	V	E	A	S	E	1	CLP07VEASE1	CLP7E,VFD,BST,AL,SS,200V,1P 3P
CLP	07	V	F	A	S	E	1	CLP07VFASE1	CLP7F,VFD,BST,AL,SS,200V,1P 3P
CLP	10	V	G	A	S	H	1	CLP10VGASH1	CLP10G,VFD,BST,AL,SS,200V,1P 3P
CLP	10	V	I	A	S	H	1	CLP10VIASH1	CLP10I,VFD,BST,AL,SS,200V,1P 3P
CLP	05	V	H	A	S	C	1	CLP05VHASC1	CLP5H,VFD,LFT,AL,SS,200V,1P 3P
CLP	05	V	A	A	S	D	3	CLP05VAASD3	CLP5A,VFD,BST,AL,SS,480V,3P
CLP	05	V	C	A	S	D	3	CLP05VCASD3	CLP5C,VFD,BST,AL,SS,480V,3P
CLP	05	V	B	A	S	D	3	CLP05VBASD3	CLP5B,VFD,BST,AL,SS,480V,3P
CLP	07	V	D	A	S	G	3	CLP07VDAAG3	CLP7D,VFD,BST,AL,SS,480V,3P
CLP	07	V	E	A	S	G	3	CLP07VEAG3	CLP7E,VFD,BST,AL,SS,480V,3P
CLP	07	V	F	A	S	G	3	CLP07VFAAG3	CLP7F,VFD,BST,AL,SS,480V,3P
CLP	10	V	G	A	S	I	3	CLP10VGAS3	CLP10G,VFD,BST,AL,SS,480V,3P
CLP	10	V	I	A	S	I	3	CLP10VIAS3	CLP10I,VFD,BST,AL,SS,480V,3P
CLP	03	V	N	A	S	A	1	CLP03VNASA1	CLP3N,VFD,BST,AL,SS,200V,1P 3P
CLP	03	V	N	A	S	B	3	CLP03VNASB3	CLP3N,VFD,BST,AL,SS,480V,3P

Pump Curve	
5_B1WPS	A
5_B2TPMS	C
5_B1.5TPMS	B
7.5_B1WPS	D
7.5_B1.5TPMS	E
7.5_B2TPMS	F
10_B1.5TPMS	G
10_B2TPMS	I
Self-Priming	H
3_B1.5TPMS	N

Volt Series V_HP	
2_3	A
4_3	B
2_5	C
4_5	D
2_7.5	E
4_7.5	G
2_10	H
4_10	I
2_15	J
4_15	K
2_20	L
4_20	M

Voltage Code	
2 = 200V (208 - 240)	
4 = 480V	
Phase	
Single or Three	1
Three Phase	3

CLPSES1P	Surge Arrestor Single Phase
CLPSES3P	Surge Arrestor Three Phase
CLPBSTSW	Flow Start Kit
CLPFLTSW100	FLOAT SWITCH, 100FT CABLE
CLPFTVLV4VF	FOOT VALVE, 4 IN VERT FLANGE

