


100 JTVF - Flow Control



Ref.	Part Description	JTV/JTVF
1	BODY	
-	NPT	—
-	BSP	—
-	SS	—
-	MM	—
-	MB	—
2	BONNET	
-	Non-Flow Control	—
-	Flow Control	—
3	Screw, Bleed	—
4	Diaphragm Assembly	231771
5	Solenoid Repair Kit	20858801
-	Solenoid O-Ring	—
-	Solenoid Filter	—
6	Handle, Solenoid	—
7	Piston, flow control	—
8	Stem, flow control	—

Note: Part numbers enclosed in brackets ( ) are not available individually, but may be sold in assemblies or kits.