



Ref.	Part Description	40BH	14070H	40B TNT 40B STD	14070 TNT 14070 STD
UPPER ASSEMBLY					
1	Fulcrum Pin	100348	100348	100348	100348
2	Arm Washers (2)	100163	100163	100163	100163
3	Arm Spring Assembly	102558	102558	102558	102558
4	Arm Spring	100349	100349	100349	100349
NOZZLES (Specify nozzle size when ordering)					
5	Straight Bore	105842	105842	105842	105842
5	Low Pressure	-	104538	-	-
5	Straight Bore W/ Vane	106131	106131	106131	106131
-	Vane	105816	105816	105816	105816
6	Spreader 7 Degree	100225	100225	100225	100225
6	Spreader 20 Degree	100226	100226	100226	100226
6	Low Pressure Spreader	-	104571	-	-
-	Rain Flow	111089	111089	111089	111089
-	Brass Plug (W Models)	100255	100255	100255	100255
BEARING ASSEMBLY					
-	Bearing Conversion Kit	-	-	110048	110048
7	Bearing Adaptor	-	-	110030	110030
8	Bearing Assy (H Style)	104152	104152	104152	104152
9	Top Seal Washer (Grn)	103709	103709	103709	103709
10	Metal Top Seal Washer	100312	100312	100312	100312
11	Bearing Spring	106237	106237	106237	106237
12	Bearing Sleeve	103670	103670	103670	103670
13	Bearing Washer (Black)	100726	100726	100726	100726
14	Wear Washer (Orange)	103058	103058	103058	103058
15	Seal Washer (Gray)	102345	102345	102345	102345
16	Bearing Nipple	103669	103669	103669	103669
17	Bearing Assembly (Old TNT Style) (A)	-	-	-	-
18	Bearing Spring	-	-	100272	100272
19	Skirted Top Seal Washer (Blk)	-	-	100297	100297
20	Top Seal Washer (White)	-	-	100298	100298
21	Bearing Sleeve	-	-	(A)	(A)
22	Wear Washer(T-Ring) (Orange)	-	-	102076	102076
23	Bearing Washer (Black)	-	-	100726	100726
24	Seal Washer (Gray)	-	-	102345	102345
25	Bearing Nipple	-	-	100302	100302
-	Bearing Assembly (Old STANDARD Style)	-	-	-	-
18	Bearing Spring	-	-	100272	100272
21	Bearing Sleeve	-	-	(A) (100294)	(A) (100294)
24	Bearing Washer (Fiber)	-	-	100156	100156
25	Bearing Nipple	-	-	(A) (100295)	(A) (100295)

(A) Not available. Use Bearing Conversion Kit #110048.

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.