



- ① RAIN BIRD FS100 SERIES 1-INCH FLOW SENSOR. WIRE TO RAIN BIRD PT3002 OR PT322 PULSE TRANSMITTER.
- ② 1-INCH DIAMETER PIPE
- ③ 1-INCH PRESSURE REDUCING NORMALLY OPEN MASTER VALVE. WIRE TO SPARE STATION ON NEAREST SATELLITE
- ④ ELL (TYPICAL)

- ⑤ TEE
- ⑥ REDUCER
- ⑦ PRESSURE REDUCING NORMALLY OPEN MASTER VALVE (SIZE AS REQUIRED). WIRE TO SPARE STATION ON NEAREST SATELLITE
- ⑧ RAIN BIRD MODEL FS350B FLOW SENSOR MOUNTED IN 2-INCH NPT THREADOLET. WIRE TO RAIN BIRD PT3002 OR PT322 PULSE TRANSMITTER

609

MAXICOM DUAL FLOW SENSORS

N.T.S.

NORMALLY OPEN MASTER VALVES

08-09-2012