



- ① FLUSH POINT (TYPICAL)  
SEE RAIN BIRD DETAIL "XFS-CV FLUSH POINT"
- ② SUB-SURFACE/ON-SURFACE DRIPLINE:  
RAIN BIRD XFS-CV SERIES DRIPLINE (TYPICAL)  
NON-POTABLE: XFS-CVP DRIPLINE
- ③ PRE-INSTALLED BARBED FITTING
- ④ QF EXHAUST HEADER
- ⑤ SEE SPECIFICATIONS FOR ROW SPACING
- ⑥ RAIN BIRD XFF-TEE
- ⑦ PERIMETER LATERALS 2" TO 4" FROM EDGE
- ⑧ IRRIGATION CONTROL VALVE:  
RAIN BIRD XCZ DRIP CONTROL ZONE KIT  
INSTALLED IN VALVE BOX
- ⑨ AREA PERIMETER
- ⑩ QF SUPPLY HEADER
- ⑪ OPERATION INDICATOR  
RAIN BIRD MODEL: OPERIND

NOTES:

1. FOR ALL QF HEADER CONNECTIONS INSTALL TLF SERIES TWIST LOCK FITTINGS
2. RECOMMENDED MINIMUM FILTRATION: 120 MESH
3. PRESSURE AT FLUSH VALVE SHALL BE MIN 15 PSI
4. 2 PSI CHECK VALVE (MAX 9' OF WATER(ELEVATION CHANGE))
5. REFER TO MAXIMUM LENGTH OF A SINGLE LATERAL CHART

**D** XFS-CV SUB-SURFACE/ON SURFACE DRIPLINE 05-17-2017  
**TRIANGULAR PATTERN W/ QF HEADER** N.T.S.