



NOTE:

1. VAN NOZZLE MAY BE SET TO CLOSED, OR IF IT IS DESIRED TO SEE SPRAY FROM THE NOZZLE, SET THE ARC TO  $\frac{1}{4}$  PATTERN. THE FLOW FROM THE NOZZLE, 0.3 GPM, SHOULD BE ACCOUNTED FOR IN THE SYSTEM DESIGN.

**D** XFS-CV SUB-SURFACE/ON-SURFACE PVC OPERATION INDICATOR ATTACHED TO QF HEADER W/ SWING JOINT

05-17-2017 N.T.S.