



- ① QF-FLUSH HEADER
- ② PRE-INSTALLED BARB FITTING
- ③ FLUSH POINT WITH PVC CAP OR OPTIONAL PVC BALL VALVE
- ④ PERIMETER OF AREA
- ⑤ PERIMETER DRIPLINE PIPE TO BE INSTALLED 2"-4" FROM PERIMETER OF AREA
- ⑥ RAIN BIRD XFS SERIES DRIPLINE (TYPICAL)
- ⑦ QF-SUPPLY HEADER
- ⑧ PVC DRIP MANIFOLD FROM RAIN BIRD CONTROL ZONE VALVE KIT (SIZED TO MEET LATERAL FLOW DEMAND)
- ⑨ PVC SCH 40 ELL (TYPICAL)
- ⑩ PVC SCH 40 RISER PIPE
- ⑪ MALE ADAPTER INSERT
- ⑫ STAINLESS STEEL, OETIKER OR MURRAY CLAMP
- ⑬ PVC SCH 40 CAP
- ⑭ PVC SCH 40 BALL VALVE
- ⑮ OPERATION INDICATOR
RAIN BIRD MODEL: OPERIND
- ⑯ XF SERIES TIE-DOWN STAKES (TDS-050)
REFER TO RAIN BIRD DRIPLINE DESIGN GUIDE FOR PROPER SPACING

NOTES:
 1. DISTANCE BETWEEN LATERAL ROWS AND EMITTER SPACING TO BE BASED ON SOIL TYPE, PLANT MATERIALS AND CHANGES IN ELEVATION. SEE INSTALLATION SPECIFICATIONS ON RAIN BIRD WEB SITE (WWW.RAINBIRD.COM) FOR SUGGESTED SPACING.
 2. LENGTH OF LONGEST DRIPLINE LATERAL SHOULD NOT EXCEED THE MAXIMUM SPACING SHOWN IN THE ACCOMPANYING TABLE.

XFS Dripline Maximum Lateral Lengths (Feet)						
Inlet Pressure psi	12" Spacing		18" Spacing		24" Spacing	
	Nominal Flow (gph)		Nominal Flow (gph)		Nominal Flow (gph)	
	0.6	0.9	0.6	0.9	0.6	0.9
15	273	155	314	250	424	322
20	318	169	353	294	508	368
30	360	230	413	350	586	414
40	395	255	465	402	652	474
50	417	285	528	420	720	488
60	460	290	596	455	780	514