LX-IVM LX-IVM Pro

10 40

16 (plus active MV's)

60 240

8

5 10

5 10

Model

- ESPLXIVM: Domestic Version 120VC
- ESPLXIVMP: Domestic Version (Pro) 120V

Accessories

- IVM Field Devices* (see next page)
- Painted Metal and Stainless Steel Pedestal/Enclosure Options available (see pg. 95)
- IQ-NCC: Network Communication Cartridge for ESP-LX Series Controllers (see pg. 106)
- See page 98 for information on Rain Bird FS-Series Flow Sensors
- Pump Start Relays (PSR110-IVM or PSR220-IVM

Field Devices

ESP-LXIVM 2-Wire Field Devices Field Devices are installed along the 2-Wire path to interface with valves and other hardware.

IVM-SOL

- Interfaces with LX-IVM to control station valves and master valves
- · Interfaces with PEB, PESB, PGA, EFB-BP and BESP Valves
- Available pre-installed in a SmartValve configuration with PEB and PGA Valves
- Rain Bird WC20 connectors (included) to be used for all splices
- · Current Draw: 0.67mA
- Model: LXIVMSOL

IVM-OUT

- Interfaces with LX-IVM to manage 3rd party valves and external gear such as pump stations
- Rain Bird WC20 connectors (included) to be used for all splices
- · Current Draw: 0.67mA
- Model: LXIVMOUT

IVM-SEN

- Interfaces with LX-IVM to control weather sensors or flow sensors
- Rain Bird WC20 connectors (included) to be used for all splice
- · Current Draw: 6mA
- Model: LXIVMSEN

IVM-SD (Surge Protection)

- IVM-SD provides surge protection on the 2-Wire path
- One every 500ft or 15 field devices
- Rain Bird WC20 connectors to be used for all splices
- · Model: LXIVMSD

lge for ESP-LX Series	Weather sensors	4	8 (including 1 Local)
	Watering windows	1 per program	
	Max run time	96 hrs	
FS-Series Flow Sensors	Start Times/program	8	
es are installed along the her hardware. valves and master valves and BESP Valves	Interstation delay	Up to 1 hour per program	
	LCD	2.5"x5" at 127x256 pixels. Monochrome with backlight	
	Front Panel Buttons	- All Buttons are back-lit - 5 Programming Button - Dedicated Language, Info and Back Buttons	
	Transformer size	1.9 amp (50 VA)	
	IVM current draw	720 uA (Standby)	
	Sensor current draw	8.4mA (Standby)	
	Max wire run	1.65 miles (2.66Km) 14 AWG in Star configuration 6.61 miles (10.63Km) Looped	
nfiguration with PEB and	No. 2-Wire paths and terminal pairs	4	
be used for all splices	Cabinet	Plastic	
	FloWatch (flow sensing)	YES - Available Options: Diagnose & Eliminate, Shut Down & Alarm, Alarm Only	
	FloManager (flow optimization)	Yes	
	Flow Rate	0 to 9999.9 gallons/min. (0.1 gallons/min. resolution)	
rty valves and external gear be used for all splices r sensors or flow sensors be used for all splices	Supported Flow Sensors	FS050P, FS075P, FS100P, FS150P, FS200P, FS300P, FS400P, FS100B, FS150B,FS200B, FS350B, FS350SS, Custom	
	Surge	20 kV int 1 IVM-SD every 500 ft. (or 15 field devices)	
	Valve type	DC Latching	
	Diagnostics Short Finding	Automatically Detect and Turn Off Wire Path Ability to turn on constant current source for field trouble shooting	
	Diagnostics Electrical History	- Daily Values (Last 30 Days) - Monthly Averages (Last 12 Mos.) - Values recorded 11:59 PM daily	
	Diagnostics – Field Device Response	List Responding and List Not Responding	
2-Wire path	Diagnostics Controller Output	Tracks Current Draw from 2-Wire Path 0.67 mA per IVM-SOL/IVM-OUT 6 mA per IVM-SEN	
	Diagnostics Watering Test	Test All Stations 1 to 10 Mins. (per station)	
all splices	Central Control Capable	Yes	
	FS100P	4 - 80	

Key Specifications

Max Programs

Master Valves

Flow sensors

Stations
Max Simulstations

Feature

For more information call the ESP-LX Hotline: 1-866-544-1406

^{*} IVM Field devices include peel-off barcode address labels