



Rain Bird® ET Manager™

Weather Reach™ Signal Provider Information Northeast

A Weather Reach Signal Provider (WRSP) broadcasts a wireless weather signal used by ET Managers to automatically control the frequency of watering. The information on this sheet, provided by the WRSP, contains essential settings that need to be programmed in the ET Manager for proper operation:

Signal Provider Code - The code consists of 10 numbers labeled A through J. The code is unique to each WRSP.

Weather Region - The Weather Region number represents a weather station managed by the Weather Reach Signal Provider. Choose a weather region that corresponds to the weather station closest to the location of the ET Manager.

Elevation - The ET Manager uses elevation to calculate ET. The weather station elevation is provided as a reference. ET Manager location elevation must be programmed to calculate ET.

Historical ET - The ET Manager uses average daily ET for each month only as a back up to real-time ET. The Average Daily Historical ET values are provided as a reference.

Weather Reach Signal Provider Information AquaSave LLC

Contact: Jim Rolfe
Email: Support@aquasave.info
Website: <http://www.aquasave.info>
Phone: 877-661-6845
Address: 31 Essex Road
Ipswich, MA 01938

Signal Provider Code		
A: 64	D: 95	G: 67
B: 255	E: 11	H: 10
C: 89	F: 213	I: 238
		J: 225

AquaSave LLC offers Weather Reach Signal Service on an annual subscription. After installing the ET Manager and programming the AquaSave Signal Provider code, complete the Weather Signal test described in the Installation Guide. The Attention light will be on and the Attention Message on the display will read, "No Signal Service." Contact AquaSave and provide them the ET Manager serial number and billing information. They will send a wireless command to activate the ET Manager. Once AquaSave activates the ET Manager, the "No Signal Service" Attention message will disappear. Web Activation is also available online at <http://www.aquasave.info>.

Weather Regions

Weather Region 9 – New Haven, Connecticut

Location: New Haven
City: New Haven, Connecticut
Elevation: 59 Feet

Average Daily Historical ET		
Jan: 0.03"	May: 0.12"	Sep: 0.11"
Feb: 0.05"	Jun: 0.15"	Oct: 0.08"
Mar: 0.06"	Jul: 0.16"	Nov: 0.06"
Apr: 0.10"	Aug: 0.16"	Dec: 0.03"

Weather Region 5 – Norwich, Connecticut

Location: Norwich
City: Norwich, Connecticut
Elevation: 56 Feet

Average Daily Historical ET		
Jan: 0.04"	May: 0.13"	Sep: 0.11"
Feb: 0.05"	Jun: 0.15"	Oct: 0.09"
Mar: 0.07"	Jul: 0.16"	Nov: 0.06"
Apr: 0.11"	Aug: 0.15"	Dec: 0.04"



Weather Region 10 – Torrington, Connecticut

Location: Torrington
City: Torrington, Connecticut
Elevation: 651 Feet

Average Daily Historical ET		
Jan: 0.03"	May: 0.14"	Sep: 0.13"
Feb: 0.04"	Jun: 0.16"	Oct: 0.10"
Mar: 0.06"	Jul: 0.17"	Nov: 0.06"
Apr: 0.11"	Aug: 0.16"	Dec: 0.03"

Weather Region 12 – Waterbury, Connecticut

Location: Waterbury
City: Waterbury, Connecticut
Elevation: 230 Feet

Average Daily Historical ET		
Jan: 0.03"	May: 0.13"	Sep: 0.11"
Feb: 0.04"	Jun: 0.15"	Oct: 0.07"
Mar: 0.07"	Jul: 0.16"	Nov: 0.05"
Apr: 0.11"	Aug: 0.14"	Dec: 0.03"

Weather Region 14 – Wilmington, Delaware

Location: Wilmington
City: Wilmington, Delaware
Elevation: 92 Feet

Average Daily Historical ET		
Jan: 0.04"	May: 0.14"	Sep: 0.12"
Feb: 0.05"	Jun: 0.17"	Oct: 0.08"
Mar: 0.08"	Jul: 0.17"	Nov: 0.06"
Apr: 0.12"	Aug: 0.16"	Dec: 0.04"

Weather Region 4 – Carver, Massachusetts

Location: Carver
City: Carver, Massachusetts
Elevation: 30 Feet

Average Daily Historical ET		
Jan: 0.04"	May: 0.12"	Sep: 0.10"
Feb: 0.04"	Jun: 0.15"	Oct: 0.07"
Mar: 0.07"	Jul: 0.16"	Nov: 0.05"
Apr: 0.10"	Aug: 0.14"	Dec: 0.04"

Weather Region 2 – Ipswich, Massachusetts

Location: Ipswich
City: Ipswich, Massachusetts
Elevation: 50 Feet

Average Daily Historical ET		
Jan: 0.03"	May: 0.12"	Sep: 0.10"
Feb: 0.04"	Jun: 0.15"	Oct: 0.07"
Mar: 0.06"	Jul: 0.16"	Nov: 0.05"
Apr: 0.10"	Aug: 0.14"	Dec: 0.03"

Weather Region 6 – Wellesley, Massachusetts

Location: Wellesley
City: Wellesley, Massachusetts
Elevation: 50 Feet

Average Daily Historical ET		
Jan: 0.03"	May: 0.10"	Sep: 0.17"
Feb: 0.04"	Jun: 0.15"	Oct: 0.16"
Mar: 0.05"	Jul: 0.17"	Nov: 0.10"
Apr: 0.07"	Aug: 0.18"	Dec: 0.05"

Weather Region 19 – Manchester, New Hampshire

Location: Manchester
City: Manchester, New Hampshire
Elevation: 165 Feet

Average Daily Historical ET		
Jan: 0.03"	May: 0.13"	Sep: 0.10"
Feb: 0.04"	Jun: 0.15"	Oct: 0.06"
Mar: 0.06"	Jul: 0.16"	Nov: 0.04"
Apr: 0.10"	Aug: 0.13"	Dec: 0.03"



Weather Region 13 – Camden, New Jersey

Location: Camden
City: Camden, New Jersey
Elevation: 20 Feet

Average Daily Historical ET		
Jan: 0.04"	May: 0.14"	Sep: 0.12"
Feb: 0.05"	Jun: 0.17"	Oct: 0.08"
Mar: 0.07"	Jul: 0.18"	Nov: 0.06"
Apr: 0.12"	Aug: 0.16"	Dec: 0.04"

Weather Region 11 – Tenafly, New Jersey

Location: Tenafly
City: Tenafly, New Jersey
Elevation: 52 Feet

Average Daily Historical ET		
Jan: 0.04"	May: 0.15"	Sep: 0.13"
Feb: 0.05"	Jun: 0.18"	Oct: 0.08"
Mar: 0.08"	Jul: 0.18"	Nov: 0.06"
Apr: 0.12"	Aug: 0.18"	Dec: 0.04"

Weather Region 110 – Albany, New York

Location: Albany
City: Albany, New York
Elevation: 250 Feet

Average Daily Historical ET		
Jan: 0.02"	May: 0.13"	Sep: 0.09"
Feb: 0.03"	Jun: 0.16"	Oct: 0.06"
Mar: 0.06"	Jul: 0.16"	Nov: 0.04"
Apr: 0.10"	Aug: 0.13"	Dec: 0.02"

Weather Region 3 – Rochester, New York

Location: Rochester
City: Rochester, New York
Elevation: 100 Feet

Average Daily Historical ET		
Jan: 0.02"	May: 0.12"	Sep: 0.09"
Feb: 0.03"	Jun: 0.16"	Oct: 0.06"
Mar: 0.05"	Jul: 0.16"	Nov: 0.04"
Apr: 0.09"	Aug: 0.13"	Dec: 0.02"

Weather Region 16 – Allentown, Pennsylvania

Location: Allentown
City: Allentown, Pennsylvania
Elevation: 338 Feet

Average Daily Historical ET		
Jan: 0.03"	May: 0.14"	Sep: 0.11"
Feb: 0.05"	Jun: 0.17"	Oct: 0.07"
Mar: 0.08"	Jul: 0.17"	Nov: 0.05"
Apr: 0.11"	Aug: 0.15"	Dec: 0.04"

Weather Region 15 – West Chester, Pennsylvania

Location: West Chester
City: West Chester, Pennsylvania
Elevation: 456 Feet

Average Daily Historical ET		
Jan: 0.04"	May: 0.14"	Sep: 0.12"
Feb: 0.05"	Jun: 0.17"	Oct: 0.08"
Mar: 0.08"	Jul: 0.17"	Nov: 0.06"
Apr: 0.12"	Aug: 0.16"	Dec: 0.04"

Weather Region 7 – Smithfield, Rhode Island

Location: Smithfield
City: Smithfield, Rhode Island
Elevation: 361 Feet

Average Daily Historical ET		
Jan: 0.04"	May: 0.13"	Sep: 0.14"
Feb: 0.05"	Jun: 0.16"	Oct: 0.08"
Mar: 0.07"	Jul: 0.17"	Nov: 0.05"
Apr: 0.10"	Aug: 0.16"	Dec: 0.04"



Rain Bird® ET Manager™
Weather Reach™ Signal Provider Information
Northeast

Weather Region 8 – Tiverton, Rhode Island

Location: Tiverton
City: Tiverton, Rhode Island
Elevation: 144 Feet

Average Daily Historical ET


Jan: 0.06"	May: 0.17"	Sep: 0.14"
Feb: 0.09"	Jun: 0.18"	Oct: 0.11"
Mar: 0.11"	Jul: 0.17"	Nov: 0.08"
Apr: 0.15"	Aug: 0.16"	Dec: 0.06"

Weather Region 1 – Burlington, Vermont


Location: Burlington
City: Burlington, Vermont
Elevation: 335 Feet

Average Daily Historical ET

Jan: 0.02"	May: 0.13"	Sep: 0.09"
Feb: 0.03"	Jun: 0.15"	Oct: 0.05"
Mar: 0.05"	Jul: 0.16"	Nov: 0.03"
Apr: 0.09"	Aug: 0.13"	Dec: 0.02"



Because of the nature of radio transmission, strength of signal varies depending upon location.



Because of the nature of radio transmission, strength of signal varies depending upon location.