



Rain Bird® ET Manager™

Weather Reach™ Signal Provider Information

A Weather Reach Signal Provider (WRSP) broadcasts a wireless weather signal used by ET Managers to automatically control the frequency of watering. The information on this sheet, provided by the WRSP, contains essential settings that need to be programmed in the ET Manager for proper operation:

Signal Provider Code - The code consists of 10 numbers labeled A through J. The code is unique to each WRSP.

Weather Region - The Weather Region number represents a weather station managed by the Weather Reach Signal Provider. Choose a weather region that corresponds to the weather station closest to the location of the ET Manager.

Elevation - The ET Manager uses elevation to calculate ET. The weather station elevation is provided as a reference. ET Manager location elevation must be programmed to calculate ET.

Historical ET - The ET Manager uses average daily ET for each month only as a back up to real-time ET. The Average Daily Historical ET values are provided as a reference.

Weather Reach Signal Provider Information

Water in Motion

Contact: Craig Otto
Email: craig@iccmnnesota.com
Phone: 763-559-1010
Address: 14060 23rd Avenue North
Plymouth, MN 55447

Signal Provider Code		
A: 64	D: 95	G: 46
B: 255	E: 11	H: 10
C: 89	F: 213	I: 172
		J: 61

Water in Motion provides Weather Reach Signal Service on an annual subscription basis. After programming the Water in Motion Signal Provider code, complete the Weather Signal test as described in the Installation Guide. The Attention light will be on and the attention Message on the display will read "No Signal Service". Activate the ET Manager by calling us and providing billing information and serial number of your product. Once you have subscribed we will send a command to activate your ET Manager. The "No Signal Service" Attention Message will disappear and your activation is completed.

Weather Regions

Weather Region 10 – Woodbury Weather Station

Location: Woodbury
City: Woodbury, Minnesota
Elevation: 875 Feet

Average Daily Historical ET		
Jan: 0.02"	May: 0.15"	Sep: 0.10"
Feb: 0.03"	Jun: 0.18"	Oct: 0.07"
Mar: 0.05"	Jul: 0.19"	Nov: 0.03"
Apr: 0.10"	Aug: 0.15"	Dec: 0.02"

Weather Region 11 – Edina Weather Station

Location: Edina
City: Edina, Minnesota
Elevation: 915 Feet

Average Daily Historical ET		
Jan: 0.02"	May: 0.15"	Sep: 0.10"
Feb: 0.03"	Jun: 0.18"	Oct: 0.07"
Mar: 0.05"	Jul: 0.19"	Nov: 0.03"
Apr: 0.10"	Aug: 0.15"	Dec: 0.02"



Rain Bird® ET Manager™

Weather Reach™ Signal Provider Information



Because of the nature of radio transmission, strength of signal varies depending upon location.