

A Weather Reach Signal Provider (WRSP) broadcasts a wireless weather signal used by ET Managers to automatically control the frequency of watering. The information on this sheet, provided by the WRSP, contains essential settings that need to be programmed in the ET Manager for proper operation:

**Signal Provider Code** - The code consists of 10 numbers labeled A through J. The code is unique to each WRSP.

**Weather Region** - The Weather Region number represents a weather station managed by the Weather Reach Signal Provider. Choose a weather region that corresponds to the weather station closest to the location of the ET Manager.

**Elevation** - The ET Manager uses elevation to calculate ET. The weather station elevation is provided as a reference. ET Manager location elevation must be programmed to calculate ET.

**Historical ET** - The ET Manager uses average daily ET for each month only as a back up to real-time ET. The Average Daily Historical ET values are provided as a reference.

---

### Weather Reach Signal Provider Information Landscape East & West

**Contact:** Kirk Lobb  
**Email:** [kirk@landscapeeast.com](mailto:kirk@landscapeeast.com)  
**Website:** <http://www.landscapeeast.com>  
**Phone:** 503-256-5302  
**Fax:** 503-297-6993  
**Address:** 8850 SE 76th Drive  
Portland, OR 97206

Signal Provider Code		
A: 64	D: 95	G: 57
B: 254	E: 11	H: 10
C: 89	F: 234	I: 196
		J: 50

Landscape East & West, Inc. (LEWI) offers ET Manager or Weather Reach signal service on a subscription basis. After installing the ET Manager and programming the signal provider code, complete the weather signal test described in the installation guide. The attention light will be on and the attention message on the display will read "No Signal Service". Contact LEWI and provide the ET Manager serial number and billing information. A wireless command will be sent to activate the ET Manager. Once LEWI activates the ET Manager, the "No Signal Service" attention message will disappear. Your ET Manager will then be operable receiving pages on an hourly basis. Thank you very much.

---

### Weather Regions

#### Weather Region 140 – Portland City Station

City: Portland, OR  
Elevation: 300 Feet

Average Daily Historical ET		
Jan: 0.02"	May: 0.12"	Sep: 0.10"
Feb: 0.04"	Jun: 0.15"	Oct: 0.05"
Mar: 0.06"	Jul: 0.16"	Nov: 0.03"
Apr: 0.09"	Aug: 0.14"	Dec: 0.02"

