

IRRIGATION CONTROLLER: RAIN BIRD IQ ESP-LXME SATELLITE CONTROLLER WITH IQ NCC GPRS CARTRIDGE IN LXMM METAL CABINET WITH OUTSIDE

WALL MOUNT. INSTALL CONTROLLER AND CABINET ON WALL

- PER MANUFACTURER'S RECOMMENDATIONS.
- (2) CELLULAR ANTENNA: RAIN BIRD IQEXTANGP GPRS/CELLULAR EXTERNAL ANTENNA (FOR USE WITH LXMM METAL CABINET ONLY)
- (3) JUNCTION BOX
- (4)1-INCH CONDUIT AND FITTINGS TO POWER SUPPLY
- (5) POWER SUPPLY WIRE
- (6)2-INCH CONDUIT AND FITTINGS FOR STATION WIRES
- (7) WIRES TO REMOTE CONTROL VALVES

NOTES:

- 1. IQ ESP-LXME CONTROLLER IS AVAILABLE IN 8- OR 12-STATION BASE MODELS. ADDITIONAL MODULES IN 4-, 8- AND 12-STATION VERSIONS MAY BE ADDED TO BRING THE CONTROLLER UP TO 48 STATIONS MAXIMUM.
- 2. FOR EASE OF INSTALLATION INTO A CONTROLLER WITH MORE THAN 24 STATIONS, INSTALL A JUNCTION BOX AT THE BASE OF CONTROLLER AND TRANSITION LARGER VALVE AND COMMON WIRES FROM FIELD TO 18 AWG MULTI CONDUCTOR WIRE TO BF USED IN CONTROLLER.
- 3. USE STEEL CONDUIT FOR ABOVE GRADE AND SCH 40 PVC CONDUIT FOR BELOW GRADE CONDITIONS.
- 4. PROVIDE PROPER GROUNDING COMPONENTS TO ACHIEVE GROUND RESISTANCE OF 10 OHMS OR LESS.
- 5. OWNER IS RESPONSIBLE FOR PROVIDING CELLULAR SERVICE CAPABLE OF INTERFACING WITH NCC GPRS CARTRIDGE. INSTALL CONTROLLER IN A LOCATION TO MAXIMIZE ANTENNA RECEPTION. CONDUCT A SURVEY OF THE SITE TO ASSURE A VIABLE AND CONSISTENT CELLULAR CONNECTION BEFORE INSTALLING CONTROLLER.

IQ ESP-LXME SATELLITE CONTROLLER WITH IQ NCC GPRS CARTRIDGE

1 - 12 - 11

IN METAL CABINET