



- ① OPERATION INDICATOR
RAIN BIRD MODEL: OPERIND
- ② PERIMETER OF AREA
- ③ SUB-SURFACE/ON-SURFACE DRIPLINE:
RAIN BIRD XFS-CV SERIES DRIPLINE (TYPICAL)
NON-POTABLE: XFS-CVP DRIPLINE
- ④ PVC EXHAUST HEADER
- ⑤ IN-LINE SWING OR SPRING CHECK VALVE
- ⑥ PERIMETER LATERALS 2" TO 4" FROM
EDGE OF LANDSCAPE
- ⑦ XFS-CV RECOMMENDED SPACING
- ⑧ PVC SUPPLY HEADER
- ⑨ FLUSH POINT (TYPICAL)
SEE RAIN BIRD DETAIL "XFS-CV FLUSH POINT"
- ⑩ TIE DOWN STAKES
RAIN BIRD TDS-050 WITH BEND
- ⑪ IRRIGATION CONTROL VALVE:
RAIN BIRD XCZ DRIP CONTROL ZONE KIT
INSTALLED IN VALVE BOX

NOTES:

1. FOR ALL XFS-CV AND POLY CONNECTIONS INSTALL XFF AND/OR XFD FITTINGS
2. RECOMMENDED MINIMUM FILTRATION: 120 MESH
3. PRESSURE AT FLUSH VALVE SHALL BE MIN 14.5 PSI
4. 2 PSI CHECK VALVE (MAX 10' OF WATER(ELEVATION CHANGE))
5. REFER TO MAXIMUM LENGTH OF A SINGLE LATERAL CHART
6. CHECK VALVE TYPE AND SIZE SHALL BE SPECIFIED BY ORIENTATION AND FLOW REQUIREMENTS NOT LINE SIZE

D XFS-CV SUB-SURFACE/ON SURFACE DRIPLINE 05-17-2017
1 VALVE - TOE OF SLOPE LAYOUT W/ PVC HEADER

N.T.S.