



- ① OPERATION INDICATOR
RAIN BIRD MODEL: OPERIND
- ② PERIMETER OF AREA
- ③ SUB-SURFACE/ON-SURFACE DRIPLINE:
RAIN BIRD XFS-CV SERIES DRIPLINE (TYPICAL)
NON-POTABLE: XFS-CVP DRIPLINE
- ④ PVC EXHAUST HEADER
- ⑤ IN-LINE SWING OR SPRING CHECK VALVE
- ⑥ PERIMETER LATERALS 2" TO 4" FROM
EDGE OF LANDSCAPE
- ⑦ PVC SUPPLY HEADER
- ⑧ FLUSH POINT (TYPICAL)
SEE RAIN BIRD DETAIL "XFS-CV FLUSH POINT"
- ⑨ TIE DOWN STAKES
RAIN BIRD TDS-050 WITH BEND
- ⑩ IRRIGATION CONTROL VALVE:
RAIN BIRD XCV DRIP CONTROL ZONE KIT
INSTALLED IN VALVE BOX

NOTES:

1. FOR ALL XFS-CV AND POLY CONNECTIONS INSTALL XFF AND/OR XFD FITTINGS
2. RECOMMENDED MINIMUM FILTRATION: 120 MESH
3. PRESSURE AT FLUSH VALVE SHALL BE MIN 14.5 PSI
4. MAX 10' OF WATER(ELEVATION CHANGE)
5. REFER TO MAXIMUM LENGTH OF A SINGLE LATERAL CHART
6. CHECK VALVE TYPE AND SIZE SHALL BE SPECIFIED BY ORIENTATION AND FLOW REQUIREMENTS NOT LINE SIZE

D XFS-CV SUB-SURFACE/ON SURFACE DRIPLINE 05-17-2017 N.T.S.
2 VALVES - INDIVIDUAL GRIDS TOE OF SLOPE LAYOUT W/ PVC HEADER