



- ① FLUSH POINT (TYPICAL)
SEE RAIN BIRD DETAIL "XFS-CV FLUSH POINT"
- ② QF EXHAUST HEADER
- ③ PRE-INSTALLED BARB FITTING
- ④ PERIMETER OF AREA
- ⑤ OPERATION INDICATOR
RAIN BIRD MODEL: OPERIND
- ⑥ PVC SCH 40 ELL (TYPICAL)
- ⑦ XF SERIES TIE-DOWN STAKES (TDS-050)
REFER TO RAIN BIRD DRIPLINE DESIGN GUIDE FOR PROPER SPACING
- ⑧ QF SUPPLY HEADER
- ⑨ SUB-SURFACE/ON-SURFACE DRIPLINE:
RAIN BIRD XFS-CV SERIES DRIPLINE (TYPICAL)
NON-POTABLE: XFS-CVP DRIPLINE
- ⑩ PVC SUPPLY PIPE FROM RAIN BIRD CONTROL ZONE KIT (SIZED TO MEET LATERAL FLOW DEMAND)
- ⑪ PERIMETER DRIPLINE PIPE TO BE INSTALLED 2"-4" FROM PERIMETER OF AREA
- ⑫ TWIST LOCK FITTING : TLF-MPT
- ⑬ BARB X BARB INSERT TEE:
RAIN BIRD XFF-TEE (TYPICAL)
- ⑭ RAIN BIRD XFS-CV SERIES DRIPLINE (TYPICAL)
- ⑮ TWIST LOCK CAP: TLF-CAP
- ⑯ PVC SCH 40 BALL VALVE
- ⑰ RAIN BIRD XF BLANK TUBING

NOTES:
 1. FOR ALL QF HEADER CONNECTIONS INSTALL TLF SERIES TWIST LOCK FITTINGS
 2. DISTANCE BETWEEN LATERAL ROWS AND EMITTER SPACING TO BE BASED ON SOIL TYPE, PLANT MATERIALS AND CHANGES IN ELEVATION. SEE INSTALLATION SPECIFICATIONS ON RAIN BIRD WEB SITE (WWW.RAINBIRD.COM) FOR SUGGESTED SPACING.
 3. LENGTH OF LONGEST DRIPLINE LATERAL SHOULD NOT EXCEED THE MAXIMUM SPACING SHOWN IN THE ACCOMPANYING TABLE.

XFS-CV Dripline Maximum Lateral Lengths (Feet)				
Inlet Pressure psi	12" Spacing		18" Spacing	
	Nominal Flow (gph)		Nominal Flow (gph)	
	0.6	0.9	0.6	0.9
20	192	136	254	215
30	289	205	402	337
40	350	248	498	416
50	397	281	573	477
60	436	309	637	529

D XFS-CV SUB-SURFACE/ON-SURFACE DRIPLINE 05-17-2017
QF HEADER CENTER FEED LAYOUT N.T.S.