

NOTES:

- 1. FOR ALL XFS-CV AND POLY CONNECTIONS INSTALL XFF AND/OR XFD FITTINGS
- 2. SEE XFS-CV TREE RING DOUBLE OR TRIPLE FOR DETAIL OF EACH SET OF RINGS.
- 3. FOR TOTAL SYSTEM FLOW GREATER THAN 5 GPM USE PVC TO CONNECT TREE RINGS, DOUBLE OR TRIPLE, AND SIZE PVC APPROPRIATELY.



- (1) SQUARE CONFIGURATION
- (2) FLUSH POINT (TYPICAL)
 SEE RAIN BIRD DETAIL "XFS-CV FLUSH POINT"
- (3) RAIN BIRD XF SERIES BLANK TUBING
- (4) TREE TRUNK
- 5 SUB-SURFACE/ON-SURFACE DRIPLINE:
 RAIN BIRD XFS-CV SERIES DRIPLINE (TYPICAL)
 NON-POTABLE: XFS-CVP DRIPLINE
- 6 XFS-CV SPACING PER RAIN BIRD RECOMMENDATION
- 7 OPERATION INDICATOR
 RAIN BIRD MODEL: OPERIND
- 8) PVC SUPPLY HEADER (SIZE BASED ON TOTAL 'FLOW)
- 9 IRRIGATION CONTROL VALVE:
 RAIN BIRD XCZ DRIP CONTROL ZONE KIT
 INSTALLED IN VALVE BOX
- (10) BARB X BARB INSERT CROSS:
 RAIN BIRD XFD-CROSS (TYPICAL)
- 11) TIE DOWN STAKE:
 RAIN BIRD TDS-050 WITH BEND

XFS-CV Sub-Surface On-Surface Dripline Multiple Tree Ring Layout Side Fed