



- ① OPERATION INDICATOR
RAIN BIRD MODEL: OPERIND
- ② IRRIGATION CONTROL VALVE:
RAIN BIRD XCZ DRIP CONTROL ZONE KIT
INSTALLED IN VALVE BOX
- ③ PERIMETER OF AREA
- ④ IN-LINE SPRING CHECK VALVE
- ⑤ PVC SUPPLY HEADER
- ⑥ PVC EXHAUST HEADER
- ⑦ SUB-SURFACE/ON-SURFACE DRIPLINE:
RAIN BIRD XFS-CV SERIES DRIPLINE (TYPICAL)
NON-POTABLE: XFS-CVP DRIPLINE
- ⑧ XFS-CV RECOMMENDED SPACING
- ⑨ PERIMETER LATERALS 2" TO 4" FROM
EDGE OF LANDSCAPE
- ⑩ TIE DOWN STAKES
RAIN BIRD TDS-050
- ⑪ FLUSH POINT (TYPICAL)
SEE RAIN BIRD DETAIL "XFS-CV FLUSH POINT"

NOTES:

1. FOR ALL XFS-CV AND POLY CONNECTIONS INSTALL XFF AND/OR XFD FITTINGS
2. RECOMMENDED MINIMUM FILTRATION: 120 MESH
3. PRESSURE AT FLUSH VALVE SHALL BE MIN 14.5 PSI
4. MAX 10' OF WATER(ELEVATION CHANGE)
5. REFER TO MAXIMUM LENGTH OF A SINGLE LATERAL CHART
6. CHECK VALVE TYPE AND SIZE SHALL BE SPECIFIED BY ORIENTATION AND FLOW REQUIREMENTS NOT LINE SIZE

D XFS-CV SUB-SURFACE/ON SURFACE DRIPLINE
QUICK LOOP LAYOUT - MEDIAN ISLAND DOWN SLOPE

05-17-2017

N.T.S.