


- (1) PVC EXHAUST HEADER
- (2)PVC SCH 40 TEE OR EL (TYPICAL)
- (3) BARB X MALE FITTING:
 RAIN BIRD XFF-MA FITTING (TYPICAL)
- (4) FLUSH POINT (TYPICAL)

 SEE RAIN BIRD DETAIL "XFS FLUSH POINT" OR

 "XFS FLUSH POINT WITH BALL VALVE"
- (5) PERIMETER OF AREA
- 6 PERIMETER DRIPLINE PIPE TO BE INSTALLED 2"-4" FROM PERIMETER OF AREA
- (7) PVC SUPPLY PIPE FROM RAIN BIRD CONTROL ZONE KIT (SIZED TO MEET LATERAL FLOW DEMAND)
- (8)PVC SUPPLY MANIFOLD
- 9 CONNECTION FROM SUPPLY MANIFOLD TO DRIPLINE (TYPICAL) SEE INSET A

- 10 SUB-SURFACE DRIPLINE:
 RAIN BIRD XF SERIES DRIPLINE (TYPICAL)
 POTABLE: XFS DRIPLINE
 NON-POTABLE: XFSP DRIPLINE
- (11) RAIN BIRD XF SERIES BLANK TUBING
- (12) BARB X BARB INSERT TEE OR CROSS:
 RAIN BIRD XFF-TEE OR
 RAIN BIRD XFD-CROSS (TYPICAL)
- (13) ½" AIR RELIEF VALVE: RAIN BIRD MODEL: ARVO50 SEE RAIN BIRD XFS DETAILS FOR AIR RELIEF INSTALLATION
- (14) BARB X FEMALE FITTING:
 RAIN BIRD XFD-TFA-075 FITTING
- (15)34" PVC NIPPLE, LENGTH AS NECESSARY



INSET A

NOTES:

- 1. DISTANCE BETWEEN LATERAL ROWS AND EMITTER SPACING TO BE BASED ON SOIL TYPE, PLANT MATERIALS AND CHANGES IN ELEVATION. SEE RAIN BIRD XF-SDI DRIPLINE INSTALLATION GUIDE FOR SUGGESTED SPACINGS.
- 2. LENGTH OF LONGEST DRIPLINE LATERAL SHOULD NOT EXCEED THE MAXIMUM LENGTH SHOWN IN THE ACCOMPANYING TABLE.
- 3. AIR RELIEF VALVE TO BE INSTALLED AT HIGH POINT OF AREA.
- 4. WHEN USING 17MM INSERT FITTINGS WITH DESIGN PRESSURE OVER 50PSI, IT IS RECOMMENDED THAT STAINLESS STEEL CLAMPS BE INSTALLED ON EACH FITTING.



XFS SUB-SURFACE DRIPLINE

12-18-2012

I.T.S.

CENTER FEED LAYOUT

	12" Spacing Nominal Flow (gph)		18" Spacing Nominal Flow (gph)		24" Spacing Nominal Flow (gph)	
Inlet Pressure psi						
	0.6	0.9	0.6	0.9	0.6	0.9
15	273	155	314	250	424	322
20	318	169	353	294	508	368
30	360	230	413	350	586	414
40	395	255	465	402	652	474
50	417	285	528	420	720	488
60	460	290	596	455	780	514

XFS Dripline Maximum Lateral Lengths (Feet)