

- (1) TRADITIONAL WIRE CONTROLLER:

 RAIN BIRD ESP-LXME2/PRO IN LXMM METAL OR LXMMSS STAINLESS

 STEEL CABINET WITH WALL MOUNT. INSTALL CONTROLLER AND CABINET
 ON WALL PER MANUFACTURER'S RECOMMENDATIONS.
- (2) JUNCTION BOX
- (3) 1-INCH CONDUIT AND FITTINGS FOR POWER SUPPLY WIRE
- (4) 2-INCH CONDUIT AND FITTINGS FOR CONTROL WIRES TO VALVES
- (5) 1-INCH OPTIONAL CONDUIT AND FITTINGS FOR IQ COMMUNICATION WIRE.

NOTES:

- 1. LXME2 CONTROLLER IS AVAILABLE IN TWO MODELS. THE LXME2 AND THE LXME2-PRO. REFER TO THE CHART BELOW FOR DIFFERENCES BETWEEN THE TWO MODELS.
- 2. USE STEEL CONDUIT FOR ABOVE GRADE AND SCH 40 PVC CONDUIT FOR BELOW GRADE CONDITIONS.
- 3. PROVIDE PROPER GROUNDING COMPONENTS TO ACHIEVE GROUND RESISTANCE OF 10 OHMS OR LESS. IF CONTROLLER IS MOUNTED INDOORS, USE POWER SUPPLY GROUND.

KEY SPECIFICATIONS

FEATURE •	GRAMS	SNOIL	VALVES	SECOND MASTER VALVE OR PUMP START	FLOW SENSOR / FLOW ZONE	R SENSORS
MODEL 🔻	MAX PROGRAMS	MAX STATIONS	MASTER VALVES	SECOND MASTE OR PUMP START	FLOW SEN	WEATHER
LXME2	40	48	1	0	0	1
LXME2 PRO	40	48	1	1	1	1



2020-04-20